

Sivoia® QS | basic programming

Verify Communication

From a Drive:

- Press and hold **Close** (■) for 5 seconds, tap **CCW** (↶) to enter Link Diagnostics mode
 - All shades/draperies will wiggle*
- Press and hold **Close** to exit Link Diagnostics Mode



From the Sivoia QS Smart Panel

- Tap **Open**, hold **Open** 5 sec., tap **Open**, hold **Open** 5 sec.
 - All shades/draperies will wiggle*
- Press and hold **Open** 5 sec. to exit Link Diagnostics mode



Open

Close

- * If any shade/drapery is not wiggling, check the wiring



Assigning shades/draperies to keypads

- Press and hold **Open** and **Close** simultaneously for 5 seconds
 - Shades/draperies that are *assigned* will move to close (down)
 - Shades/draperies that are *unassigned* will move to open (up)
- Tapping **Open** jogs “forward,” **Close** jogs “backward” through the shades/draperies
- Tap **Lower** (⏏) to assign or **Raise** (⏏) to unassign a shade/drapery
- Press and hold **Open** and **Close** simultaneously for 5 seconds to exit
 - Shades/draperies will return to their original positions

(continued)

Sivoia® QS | advanced programming

Setting limits from a keypad

- Press and hold **Open** and **Raise** () simultaneously for 5 seconds
- Tapping **Open** jogs “forward,” **Close** jogs “backward” through the assigned shades/draperies
- Use **Raise** and **Lower** () to adjust shade/drapery position
- Press and hold **Open** to store the open limit or **Close** to store the close limit
- Press and hold **Open** and **Raise** simultaneously for 5 seconds to exit

Storing Presets from a keypad

- Store the current position of the shade/drapery by pressing and holding the desired **Preset** button for 5 seconds

Individual Level Adjust

- Press and hold **Open** and **Close** simultaneously for 5 seconds
 - Shades/draperies that are assigned will move to close (down)
 - Shades/draperies that are unassigned will move to open (up)
- Tap the desired **Preset** button (shades/draperies will move to currently stored position)
- Tap **Open** to jog “forward,” **Close** to jog “backward” to select an assigned shade/drapery
- Use **Raise** and **Lower** to adjust shade/drapery position
- Select and adjust position of additional assigned shades/draperies
- Store the new position of the shades/draperies by pressing and holding the desired **Preset** button for 5 seconds
- Press and hold **Open** and **Close** simultaneously for 5 seconds to exit